

Quick Instructions – aluminium mirror track

Supplied is chrome aluminium track, support track, end caps & mirror. The support track is screwed onto the wall, bottom first without mirror. Then screw the top track with mirror in place. The chrome track clips over the support track by pressing on an angle down hard on the support track, you will feel it click into place. If you need to remove the chrome track it is sometimes easier to pry with a screwdriver at the base. The end caps fit neatly on the ends to cover the cut.

Step by step

Remove chrome capping which fits tightly over support track

- Drill a number of holes through support track for the screw holes (this is not the chrome piece)
- Screw bottom support track onto wall – check track is level. (use plasterboard fixings if into plasterboard, and or extra screws) allow a small space under the track for the chrome cap to fit.
- Place mirror in track and screw top support track in place – check track is level and is not hard against the mirror, a 1-2mm gap is recommended.
- Press chrome capping into place, it clips at the top edge first then hard on the bottom edge, you will feel it clip into place.
- Place endcaps into ends of track, they are “handed”, ensure the small radius corners are at the front, press hard to lock into place.